

welcome

to hands-free
communications from
Plantronics

With a Plantronics headset, you will experience a level of comfort and on-the-job freedom you may have never felt before. To obtain maximum performance, please read the adapter installation and usage information contained in this manual. For information on headset operation, please refer to your headset manual.

If you have any questions, please call Plantronics:
1 (800) 544-4660

Installation


for units with a push-to-talk button

Your headset is equipped with a push-to-talk button that can be adjusted with a screwdriver to be either lockable or nonlockable. When the button is depressed or locked in the ON position, the microphone is turned on and will transmit your voice.

how to select the lockable or nonlockable switch position


lockable position

Note that the selector slot is aligned vertically. The push-to-talk button can be depressed momentarily or locked in the ON position by first depressing then sliding the button until it locks.




nonlockable position

Turn the selector horizontally. The push-to-talk button can be depressed momentarily when you wish to speak.



plug prong adapters

Simply plug into the appropriate jack in your station or jackset. The adapters are universal and may be positioned so that either side is visible.



Service and warranty repairs

How to Obtain Warranty Repairs

To obtain warranty repairs, return the unit(s), shipping prepaid, to:

Plantronics Service Center Operations
345 Encinal Street
Santa Cruz, CA 95061-0635

Please use the original container, or pack the unit(s) in a sturdy carton with sufficient packing material to prevent damage.

Include the following information:

1. A proof-of-purchase indicating model number and date of purchase
2. Bill-to address
3. Ship-to address
4. Number and description of units shipped
5. Name and telephone number of person to call, should contact be necessary
6. Reason for return and description of your problem

Return shipping charges to the customer are paid by Plantronics only for in-warranty equipment not requiring chargeable repairs. For out-of-warranty equipment, and for in-warranty equipment requiring chargeable repairs, shipping charges are prepaid by Plantronics and billed to the customer. Damage occurring during shipment is deemed the responsibility of the carrier, and claims should be made directly with such carrier.

Plantronics reserves the right to refuse to service any headset if it has been altered, modified, or serviced by someone other than Plantronics Service Center Operations.

How to Obtain Out-of-Warranty Repairs

To obtain out-of-warranty repairs, please contact Plantronics Service Center Operations:

phone (831) 426-5868, (800) 544-4660, fax (800) 279-0162.
For more information: www.plantronics.com

fcc registration information

FEDERAL COMMUNICATIONS COMMISSION
(FCC) INFORMATION

FCC Requirements - Part 68

1. The FCC has established Rules which permit this device to be directly connected to the telephone network. Standardized jacks are used for these connections. This equipment should not be used on party lines or coin phones.
2. If this device is malfunctioning, it may also be causing harm to the telephone network; this device should be disconnected until the source of the problem can be determined and until repair has been made. If this is not done, the telephone company may temporarily disconnect service.
3. The telephone company may make changes in its technical operations and procedures; if such changes affect the compatibility or use of this device, the telephone company is required to give adequate notice of the changes. You will be advised of your right to file a complaint with the FCC.
4. If the telephone company requests information on what equipment is connected to their lines, inform them of:
 - a. The telephone number to which this unit is connected.
 - b. The ringer equivalence number.
 - c. The USOC jack required (RJ-11C).
 - d. The FCC Registration Number.

Items (b) and (d) are indicated on the label. The Ringer Equivalence Number (REN) is used to determine how many devices can be connected to your telephone line. In most areas, the sum of the RENs of all devices on any one line should not exceed five (5.0). If too many devices are attached, they may not ring properly.

Service Requirements

In the event of equipment malfunction, all repairs should be performed by Plantronics or an authorized agent. It is the responsibility of users requiring service to report the need for service to Plantronics or one of its authorized agents. Service can be obtained at the facility listed in the Warranty Information section.

